

SUMMARY OF RISK MANAGEMENT MEASURES FOR THE USE OF TRICHLORO(VINYL)SILANE CAS 75-94-5

Chemical safety assessments have been performed to assess the risk associated with the following uses :

Identified use	Sector of Use - main user groups (SU)	Sector of Use – sectors of end-use	Preparation Category (PC)	Process category (PROC)	Article category (AC)	Environmental Release Category (ERC)
Monomer	SU3	SU8, 9	PC19	PROC1, 2, 3, 8b, 9	-	ERC6c, ERC 6d
Intermediate	SU3	SU8, 9	PC19	PROC1, 2, 3, 8b, 9	-	ERC6a
Laboratory chemical	SU3	SU24	PC21	PROC15	-	N/A

Safe use has been demonstrated by calculation of risk characterisation ratios. These are based on the following risk management measures:

Exposure scenario	Description	General measures	Specific Human Health risk management measures	Specific Environment risk management measures
ES1	Production (site specific)	(i) Rigorous containment and safe handling in line with industry best practice. (ii) Procedural and technological control using Best Available Technique (BAT)	(i) Local Exhaust ventilation (LEV) (ii) Personal Protective Equipment (PPE): Gloves/ gauntlets (5-layer laminate of PE and EVOH (4H) or Butyl & Viton types recommended); Full-face respirator with ABEK-filter; Goggles or face shield; and Self-contained, positive pressure breathing apparatus (for prolonged or high exposures) (iii) Specific workers' training (iv) Duration of exposure: <15 min for PROC8b and 9	(i) Use of air emission abatement equipment such as incinerators and scrubbers (ii) Treatment of effluent in biological waste water treatment plant. (iii) Incineration of waste
ES2 and ES3	Monomer and Chemical intermediate	Rigorous containment and safe handling in line with industry best practice.	(i) Local Exhaust ventilation (LEV) (ii) Personal Protective Equipment (PPE): Gloves/ gauntlets (5-layer laminate of PE and EVOH (4H) or Butyl & Viton types recommended); Full-face respirator with ABEK-filter; Goggles or face shield and Self-contained, positive pressure breathing apparatus (for prolong or high exposures) (iii) Specific workers' training (iv) Duration of exposure: <15 min for PROC2, 3, 8b and 9	(i) Use of air emission abatement equipment such as incinerators, scrubbers and fabric filters is applicable as a 'best practice'. (ii) Treatment of effluent in waste water treatment plant.
ES4	Laboratory reagent	Good Laboratory Practice (GLP)	(i) Local Exhaust ventilation (Fume cupboard) (ii) Personal Protective Equipment (PPE): Gloves/ gauntlets (5-layer laminate of PE and EVOH (4H) or Butyl & Viton types recommended) (iii) Basic workers' training (iv) Duration of exposure: 15 min to 1 h	N/A

Guidance on safe use

This is a relevant extract from more extended information in IUCLID section 11 and the eSDS.

Handling :

Advice on safe handling: Do not breathe vapours or spray mist. Avoid contact with skin, eyes and clothing. Wash hands before breaks and immediately after handling the product. Ensure adequate ventilation, especially in confined areas. Use proper bonding and grounding during material transfer. Other precautions: Releases hydrogen gas (flammable) on contact with strong acid or strong base. May release hydrogen on standing in container. Since this product can, under certain conditions, evolve hydrogen gas, care should be taken to avoid exposure to flame, excessive heat, and sparks. The evolution of hydrogen gas is accelerated by the presence of metals such as lead (in solders), and zinc (in galvanised equipment), and alkalies. Care should, therefore, be taken to avoid contaminants in storage containers. Store containers in a well-ventilated area. Open them cautiously, in case they may be under a slight pressure. Have good ventilation and suitable protective equipment in areas where containers will be opened.

Storage :

Requirements for storage areas and containers : Keep container closed. Keep away from heat, sparks and flame.

Engineering measures :

Use only in an area equipped with a safety shower. Eye wash bottle with pure water

General (mechanical) room ventilation is expected to be satisfactory if handled at low temperatures or in covered equipment. Special, local ventilation is needed at points where vapors can be expected to escape to the workplace air. Personal protective equipment Respiratory protection : Respirator with an ABEK filter; at high concentration use respiratory protection with independent air supply.

Hand protection : Advise : Protective gloves made of : butyl-rubber, Neoprene, Polyvinylchloride
Eye protection : Safety glasses
Skin and body protection : Safety shoes, Protective suit